



S27





```

J%$" $
          hY bYh          `]bYj hm          6CCH          7HF@
          6CCH          Wwf`ZV          7HF@          Wwf`ZW
G) +/G&-/G&+
          %
          &
          à          à          à          7CA @DH          à
  
```

波特率 —— 9600

数据位 —— 8

奇偶校验 —— 无

停止位 —— 1

流量控制 —— 无

Wwf`ZW 7HF@

```

( (
==== Ctrl Tools Menu("Ctrl+Q" to quit) ====
*****
      File management utilities.
*****
      0. List information about the files.
      1. Remove a file.
      2. Rename or Move a file.
      3. Format flash filesystem.
*****
Press a key to run the command:
) % VwbZ] ["hYl h
  
```



```
==== Ctrl Tools Menu("Ctrl+Q" to quit) ====
*****
File management utilities.
*****
0. List information about the files.
1. Remove a file.
2. Rename or Move a file.
3. Format flash filesystem.
*****
```

Press a key to run the command: 1
The filename you want to remove:config.txt

& V\bZ] ["hYI h V\bZ] ["VU_
V\bZ] ["hYI h V\bZ] ["VU_

```
==== Ctrl Tools Menu("Ctrl+Q" to quit) ====
*****
File management utilities.
*****
0. List information about the files.
1. Remove a file.
2. Rename or Move a file.
3. Format flash filesystem.
*****
```

```
Press a key to run the command: 2
The old filename:config.txt
The new filename:config.bak
```

* V\bZ] ["hYI h



Hot Commands:

F1. tftp

Ctrl>quit

==== Ctrl Tools Menu("Ctrl+Q" to quit)====

TOP menu items.

0. Tftp utilities.

1. XModem utilities.

2. Run Main.

3. Run a Executable file.

4. File management utilities.

5. Scattered utilities.

Press a key to run the command: 3

Enter the Executable filename: gnos.bin

+
VtbZ] ["VU_

VtbZ] ["hYl h